

CABLE	AMERICAST	0899
CABLE	BELL SOUTH	0900
CABLE	DIRECTOR	0476
CABLE	GENERAL INSTRUMENT	0476 0810 0276
CABLE	GOLDSTAR	0144
CABLE	HAMLIN	0009
CABLE	JERROLD	0476 0810 0276
CABLE	MEMOREX	0000
CABLE	MOTOROLA	0476 0810 0276
CABLE	PACE	0237
CABLE	PANASONIC	0000 0107
CABLE	PARAGON	0000
CABLE	PHILIPS	0305 0317
CABLE	PIONEER	0877 1877 0144 0533
CABLE	PULSAR	0000
CABLE	QUASAR	0000
CABLE	RUNCO	0000
CABLE	SAMSUNG	0144
CABLE	SCIENTIFIC ATLANTA	0877 1877 0477
CABLE	SONY	1006
CABLE	SUPERCABLE	0276
CABLE	TOSHIBA	0000
CABLE	ZENITH	0000 0525 0899
DVD	APEX DIGITAL	0672 0717 0794 1056 0755 0797 1100 0796 1061
DVD	AXION	1072
DVD	BLAUPUNKT	0717
DVD	BLUE PARADE	0571
DVD	CINEVISION	0876

DVD	CURTIS MATHES	1087
DVD	CYBERHOME	1024 1023 0816
DVD	DAEWOO	0784
DVD	DENON	0490
DVD	DUAL	1068
DVD	DVD2000	0521
DVD	EMERSON	0591 0675
DVD	ENTERPRISE	0591
DVD	FISHER	0670
DVD	FUNAI	0675
DVD	GE	0522 0815 0717
DVD	Go VIDEO	0744 0715 0783
DVD	GPX	0699
DVD	GREENHILL	0717
DVD	HITACHI	0573
DVD	HITEKER	0672
DVD	JVC	0558 0623
DVD	KENWOOD	0490 0534
DVD	KLH	0717 1020
DVD	KOSS	0651
DVD	LASONIC	0798
DVD	MAGNAVOX	0503 0675
DVD	MARANTZ	0539
DVD	MICROSOFT	0522
DVD	MINTEK	0839 0717
DVD	MITSUBISHI	0521 1521
DVD	NESA	0717
DVD	NORCENT	1003
DVD	ONKYO	0503
DVD	ORITRON	0651

DVD	PANASONIC	0490 1762
DVD	PHILIPS	0503 0539 0646
DVD	PIONEER	0525 0571
DVD	POLK AUDIO	0539
DVD	PROSCAN	0522
DVD	QWESTAR	0651
DVD	RCA	0522 0571 0717
DVD	ROTEL	0623
DVD	ROWA	0823
DVD	SAMSUNG	0573 1075 0820
DVD	SANYO	0670
DVD	SHINSONIC	0533 0839
DVD	SONY	0533 1533 0864 1033
DVD	SYLVANIA	0675
DVD	SYMPHONIC	0675
DVD	TECHNICS	0490
DVD	THETA DIGITAL	0571
DVD	TOSHIBA	0503
DVD	TREDEX	0799
DVD	URBAN CONCEPTS	0503
DVD	XBOX	0522
DVD	YAMAHA	0490 0539 0545
DVD	ZENITH	0503 0591
SATELLITE	ALPHASTAR	0772
SATELLITE	DIRECTV	0392 0566 0639 0247 0749 1749 0724 0819 1856
SATELLITE	DISH NETWORK SYSTEM	1005 0775
SATELLITE	DISHPRO	1005 0775
SATELLITE	ECHOSTAR	1005 0775
SATELLITE	EXPRESSVU	0775

SATELLITE	GE	0566
SATELLITE	GENERAL INSTRUMENT	0869
SATELLITE	GOI	0775
SATELLITE	HITACHI	0819
SATELLITE	HTS	0775
SATELLITE	HUGHES NETWORK SYSTEMS	"0749, 1749"
SATELLITE	JVC	0775
SATELLITE	MAGNAVOX	0724 0722
SATELLITE	MEMOREX	0724
SATELLITE	mitsubishi	0749
SATELLITE	MOTOROLA	0869
SATELLITE	NEXT LEVEL	0869
SATELLITE	PANASONIC	0247 0701
SATELLITE	PAYSAT	0724
SATELLITE	PHILIPS	0749 1749 0724 0722
SATELLITE	PROSCAN	0392 0566
SATELLITE	RADIO SHACK	0869
SATELLITE	RCA	0392 0566 0855 0143
SATELLITE	SAMSUNG	1276
SATELLITE	SKY	0856
SATELLITE	SONY	0639 1639
SATELLITE	STAR CHOICE	0869
SATELLITE	TOSHIBA	0749 1749 0790 1285
SATELLITE	ULTIMATE TV	0392 0639
SATELLITE	UNIDEN	0724 0722
SATELLITE	ZENITH	0856 1856
TV	AOC	0030
TV	ADMIRAL	0093 0463
TV	ADVENT	0761 0842

TV	AIKO	0092
TV	AKAI	0702 0030 0672 0812
TV	ALFIDE	0672
TV	AMERICA ACTION	0180
TV	ANAM	0180
TV	APEX DIGITAL	0748 0765 0767
TV	AUDIOVOX	0451 0180 0092 0623
TV	BAYSONIC	0180
TV	BELL & HOWELL	0154
TV	BRADFORD	0180
TV	BROKSONIC	0236 0463
TV	CXC	0180
TV	CANDLE	0030
TV	CARNIVALE	0030
TV	CARVER	0054
TV	CELEBRITY	0000
TV	CELERA	0765
TV	CHANGHONG	0765
TV	CINERAL	0451 0092
TV	CITIZEN	0060 0030 0092
TV	CLARION	0180
TV	CONTEC	0180
TV	CRAIG	0180
TV	CROSLEY	0054
TV	CROWN	0180 0672
TV	CROWN MUSTANG	0672
TV	CURTIS MATHES	0047 0054 0154 0451 0093 0060 0702 0030 0145 0166 1147 1347
TV	DAEWOO	0451 1661 0092 0672 0623
TV	DENON	0145

TV	DUMONT	0017
TV	DURABRAND	0003 0171 0178 0180 0463 1034
TV	ELECTROBAND	0000
TV	EMERSON	0154 0236 0463 0180 0178 0171 0623
TV	ENVISION	0030
TV	FISHER	0154
TV	FUJITSU	0683 0809
TV	FUNAI	0180 0171
TV	FUTURETECH	0180
TV	GE	0047 0051 0451 0178 1147 1347
TV	GATEWAY	1755 1756
TV	GIBRALTER	0017 0030
TV	GOLDSTAR	0030 0178
TV	GRADIENTE	0053
TV	GRUNDIG	0672
TV	GRUNPY	0180
TV	HALLMARK	0178
TV	HARMAN/KARDON	0054
TV	HARVARD	0180
TV	HAVERMY	0093
TV	HELLO KITTY	0451
TV	HITACHI	0145 1145
TV	INFINITY	0054
TV	INTEQ	0017
TV	JBL	0054
TV	JCB	0000
TV	JVC	0463 0053
TV	JENSEN	0761
TV	KEC	0180

TV	KLH	0765 0767
TV	KTV	0180 0030
TV	KENWOOD	0030
TV	KIOTO	0706
TV	LXI	0047 0054 0154 0156 0178
TV	MGA	0150 0030 0178
TV	MTC	0060 0030
TV	MAGNAVOX	0054 0706 0030 1454 1254
TV	MARANTZ	0054 0030
TV	MATSUSHITA	0250 0650
TV	MEGATRON	0178 0145
TV	MEMOREX	0154 0250 0463 0150 0178
TV	MIDLAND	0047 0017 0051
TV	MITSUBISHI	0093 0150 1250 0178 0836
TV	MOTOROLA	0093
TV	MULTITECH	0180
TV	NAD	0156 0178 0866
TV	NEC	0030 1704 0704
TV	NTC	0092
TV	NIKKO	0030 0178 0092
TV	NORCENT	0748 0824
TV	ONWA	0180
TV	OPTIMUS	0154 0250 0166 0650
TV	OPTONICA	0093
TV	ORION	0236 0463
TV	PANASONIC	0051 0250 0650
TV	PENNEY	0047 0156 0051 0060 0030 0178 1347
TV	PHILCO	0054 1661 0463 0030 0145
TV	PHILIPS	0054 1454 0690

TV	PILOT	0030
TV	PIONEER	0166 0866
TV	PORTLAND	0092
TV	PRIMA	0761
TV	PRISM	0051
TV	PROSCAN	0047
TV	PROTON	0178
TV	PULSAR	0017
TV	QUASAR	0051 0250 0650
TV	RCA	0047 1047 1147 1247 1347 1447 1547
TV	RADIO SHACK	0047 0154 0180 0030 0178
TV	REALISTIC	0154 0180 0030 0178
TV	RUNCO	0017 0030
TV	SSS	0180
TV	SAMPO	0030 1755
TV	SAMSUNG	0060 0702 0030 0178 0812
TV	SANSEI	0451
TV	SANSUI	0463
TV	SANYO	0154
TV	SCOTCH	0178
TV	SCOTT	0236 0180 0178
TV	SEARS	0047 0054 0154 0156 0178 0171
TV	SEMIVOX	0180
TV	SEMP	0156
TV	SHARP	0093
TV	SHENG CHIA	0093
TV	SONY	0000 1100 0810
TV	SOUNDESIGN	0180 0178
TV	SQUAREVIEW	0171

TV	STARLITE	0180
TV	SUPREME	0000
TV	SYLVANIA	0054 0030 0171
TV	SYMPHONIC	0180 0171
TV	TMK	0178
TV	TNCi	0017
TV	TVS	0463
TV	TANDY	0093
TV	TECHNICS	0051 0250
TV	TECHWOOD	0051
TV	TEKNIKA	0054 0180 0150 0060 0092
TV	TELEFUNKEN	0702
TV	TOSHIBA	0154 0156 0060 1356 1656 1704 0650
TV	TOSHIBA	1256
TV	VECTOR RESEARCH	0030
TV	VICTOR	0053
TV	VIDIKRON	0054
TV	VIDTECH	0178
TV	VIEWSONIC	1755
TV	WARDS	0054 0030 0178 0866
TV	WAYCON	0156
TV	WHITE WESTINGHOUSE	0463 0623
TV	YAMAHA	0030
TV	ZENITH	0017 0463 0178 0092
TV DVD COMBO	SYLVANIA	0675
TV VCR COMBO	AMERICA ACTION	0278
TV VCR COMBO	AUDIOVOX	0278

TV VCR COMBO	BROKSONIC	0479 1479
TV VCR COMBO	CITIZEN	1278
TV VCR COMBO	COLT	0072
TV VCR COMBO	CURTIS MATHES	1035
TV VCR COMBO	DAEWOO	1278
TV VCR COMBO	EMERSON	0479 1479 1278
TV VCR COMBO	FUNAI	0000
TV VCR COMBO	GE	0240 1035 0807 1060
TV VCR COMBO	GOLDSTAR	1237
TV VCR COMBO	HARLEY DAVIDSON	0000
TV VCR COMBO	HITACHI	0000
TV VCR COMBO	LLOYD'S	0000
TV VCR COMBO	MAGNASONIC	1278
TV VCR COMBO	MAGNAVOX	0000 1781
TV VCR COMBO	MAGNIN	0240
TV VCR COMBO	MEMOREX	0162 1237
TV VCR COMBO	MGA	0240
TV VCR	MITSUBISHI	0807

COMBO		
TV VCR		
COMBO	OPTIMUS	0162
TV VCR		
COMBO	ORION	1479 0479
TV VCR		
COMBO	PANASONIC	0162 1035
TV VCR		
COMBO	PENNEY	0240 1035 1237
TV VCR		
COMBO	QUASAR	0162 1035
TV VCR		
COMBO	RADIO SHACK	0000
TV VCR		
COMBO	RCA	0240 0807 1060 1035
TV VCR		
COMBO	SAMSUNG	1014
TV VCR		
COMBO	SANSUI	0000 1479 0479
TV VCR		
COMBO	SANYO	0240
TV VCR		
COMBO	SEARS	0000 1237
TV VCR		
COMBO	SONY	0000 1232
TV VCR		
COMBO	SYLVANIA	1781
TV VCR		
COMBO	SYMPHONIC	0000
TV VCR		
COMBO	THOMAS	0000
TV VCR		
COMBO	TOSHIBA	1145 0845
TV VCR		
COMBO	ZENITH	0000 1479 0479

VCR	ABS	1972
VCR	ADMIRAL	0048 0209
VCR	ADVENTURA	0000
VCR	AIKO	0278
VCR	AIWA	0037 0000
VCR	AKAI	0041
VCR	ALIENWARE	1972
VCR	AMERICA ACTION	0278
VCR	AMERICAN HIGH	0035
VCR	ASHA	0240
VCR	AUDIOVOX	0037 0278
VCR	BEAUMARK	0240
VCR	BELL & HOWELL	0104
VCR	BROKSONIC	0184 0121 0209 1479 0479
VCR	CALIX	0037
VCR	CANON	0035
VCR	CARVER	0081
VCR	CCE	0072 0278
VCR	CITIZEN	0037 0278 1278
VCR	COLT	0072
VCR	CRAIG	0037 0047 0240 0072
VCR	CURTIS MATHES	0060 0035 0162 0041 1035
VCR	CYBERNEX	0240
VCR	CYBERPOWER	1972
VCR	DAEWOO	0045 0278 1278
VCR	DENON	0042
VCR	DURABRAND	0038 0039
VCR	DYNATECH	0000
VCR	ELECTROHOME	0037
VCR	ELECTROPHONIC	0037

VCR	EMEREX	0032
VCR	EMERSON	0037 0184 0000 0121 0043 0209 0278 0479 1479 1278
VCR	FISHER	0047 0104
VCR	FUJI	0035 0033
VCR	FUNAI	0000
VCR	GARRARD	0000
VCR	GATEWAY	1972
VCR	GE	0060 0035 0240 0807 1060 1035
VCR	GO VIDEO	0432
VCR	GOLDSTAR	0037 0038 1237
VCR	GRADIENTE	0000
VCR	HARLEY DAVIDSON	0000
VCR	HARMAN/KARDON	0081 0038
VCR	HARWOOD	0072
VCR	HEWLETT PACKARD	1972
VCR	HI-Q	0047
VCR	HITACHI	0000 0042 0041
VCR	HUGHES NETWORK SYSTEMS	0042
VCR	IBUYPOWER	1972
VCR	JENSEN	0041
VCR	JVC	0067 0041
VCR	KEC	0037 0278
VCR	KENWOOD	0067 0041 0038
VCR	KLH	0072
VCR	KODAK	0035 0037
VCR	LLOYD'S	0000
VCR	LOGIK	0072
VCR	LXI	0037
VCR	MAGNASONIC	1278

VCR	MAGNAVOX	0035 0039 0081 0000 1781
VCR	MAGNIN	0240
VCR	MARANTZ	0035 0081
VCR	MARTA	0037
VCR	MATSUSHITA	0035 0162
VCR	MEDIA CENTER PC	1972
VCR	MEI	0035
VCR	MEMOREX	0035 0162 0037 0048 0039 0047 0240 0000 0104 0209 0479 1237
VCR	MGA	0240 0043
VCR	MGN TECHNOLOGY	0240
VCR	MICROSOFT	1972
VCR	MIND	1972
VCR	MINOLTA	0042
VCR	MITSUBISHI	0067 0043 0807
VCR	MOTOROLA	0035 0048
VCR	MTC	0240 0000
VCR	MULTITECH	0000 0072
VCR	NEC	0104 0067 0041 0038
VCR	NIKKO	0037
VCR	NOBLEX	0240
VCR	NORTHGATE	1972
VCR	OLYMPUS	0035
VCR	OPTIMUS	1062 0162 0037 0048 0104 0432
VCR	ORION	0184 0209 1479 0479
VCR	PANASONIC	1062 0035 0162 1035 0616
VCR	PENNEY	0035 0037 0240 0042 0038 1035 1237
VCR	PENTAX	0042
VCR	PHILCO	0035

VCR	PHILIPS	0035 0081 0618
VCR	PILOT	0037
VCR	PIONEER	0067
VCR	POLK AUDIO	0081
VCR	PROFITRONIC	0240
VCR	PROSCAN	0060 1060
VCR	PROTEC	0072
VCR	PULSAR	0039
VCR	QUASAR	0035 0162 1035
VCR	RADIO SHACK	0000
VCR	RADIX	0037
VCR	RANDEX	0037
VCR	RCA	0060 0240 0042 1035 0880 0807 1060
VCR	REALISTIC	0035 0037 0048 0047 0000 0104
VCR	REPLAY TV	0616 0614
VCR	RUNCO	0039
VCR	SAMSUNG	0240 0045 1014
VCR	SANKY	0048 0039
VCR	SANSUI	0000 0067 0209 0041 1479 0479
VCR	SANYO	0047 0240 0104
VCR	SCOTT	0184 0045 0121 0043
VCR	SEARS	0035 0037 0047 0000 0042 0104 1237
VCR	SHARP	0048 0807
VCR	SHINTOM	0072
VCR	SHOGUN	0240
VCR	SINGER	0072
VCR	SONIC BLUE	0614 0616
VCR	SONY	0035 0032 0033 0000 1232 0636
VCR	STS	0042

VCR	SYLVANIA	0035 0081 0000 0043 1781
VCR	SYMPHONIC	0000
VCR	TAGAR SYSTEMS	1972
VCR	TATUNG	0041
VCR	TEAC	0000 0041
VCR	TECHNICS	0035 0162
VCR	TEKNIKA	0035 0037 0000
VCR	THOMAS	0000
VCR	TIVO	0636 0618
VCR	TMK	0240
VCR	TOSHIBA	0045 0043 1145 0845
VCR	TOTEVISION	0037 0240
VCR	TOUCH	1972
VCR	UNITECH	0240
VCR	VECTOR	0045
VCR	VECTOR RESEARCH	0038
VCR	VIDEO CONCEPTS	0045
VCR	VIDEOMAGIC	0037
VCR	VIDEOSONIC	0240
VCR	VIEWSONIC	1972
VCR	VILLAIN	0000
VCR	WARDS	0060 0035 0048 0047 0081 0240 0000 0042 0072
VCR	WHITE WESTINGHOUSE	0209 0072
VCR	XR-1000	0035 0000 0072
VCR	YAMAHA	0038
VCR	ZENITH	0039 0033 0000 0209 1479 0479
VCR	ZT GROUP	1972
VCR DVD COMBO	APEX DIGITAL	1061

VCR DVD COMBO	GO VIDEO	0744 0715
VCR DVD COMBO	HITACHI	0000
VCR DVD COMBO	PANASONIC	1762
VCR DVD COMBO	RCA	0060
VCR DVD COMBO	SAMSUNG	1075 0820
VCR DVD COMBO	SANYO	0104
VCR DVD COMBO	SONY	0864
VCR DVD COMBO	SYLVANIA	0675 0000
VCR DVD COMBO	SYMPHONIC	0675 0000
VCR DVD COMBO	TOSHIBA	0503
SATELLITE PVR COMBO	ECHOSTAR	1005
SATELLITE PVR COMBO	EXPRESSVU	0775
SATELLITE PVR COMBO	PROSCAN	0392
SATELLITE PVR COMBO	RCA	0392
SATELLITE PVR COMBO	SONY	0639
PVR	PANASONIC	0616
PVR	PHILIPS	0618
PVR	REPLAYTV	0614 0616
PVR	SONIC BLUE	0616 0614

PVR	SONY	0636
PVR	TIVO	0636 0618
CABLE PVR COMBO	MOTOROLA	1376
CABLE PVR COMBO	PIONEER	0187 0007
CABLE PVR COMBO	SCIENTIFIC ATLANTA	1877
TV VCR DVD COMBO	SHARP	0807